

Volumetric Flow Meter VME

Technical data



Ferdinand Schad KG
Steigstraße 25-27
D-78600 Kolbingen
Telephone +49 (0) 74 63 - 980 - 0
Fax +49 (0) 74 63 - 980 - 200
info@schako.de
www.schako.de




Volumetric Flow Meter VME

Effective pressure (supply air)

Volumetric flow meter VME integrated into the connection piece of the plenum box

VME-Z $\varnothing D=98$

VME-Z $\varnothing D=123$



Damper position:

100 % = OPEN

0 % = CLOSED

Legend

V_{ZU} (m³/h) = Supply air volume

V_{ZU} [l/s] = Supply air volume

ρ (kg/m³) = Density

Δp_w (Pa) = Effective pressure




Volumetric Flow Meter VME

Effective pressure (supply air)

Volumetric flow meter VME integrated in the connection piece of the plenum box

VME-Z $\varnothing D=138$

VME-Z $\varnothing D=158$



Damper position:

- 100 % = OPEN
- 0 % = CLOSED

Legend


- V_{ZU} (m^3/h) = Supply air volume
- V_{ZU} [l/s] = Supply air volume
- ρ (kg/m^3) = Density
- Δp_w (Pa) = Effective pressure

Volumetric Flow Meter VME



Effective pressure (supply air)

Volumetric flow meter VME integrated in the connection piece of the plenum box

VME-Z $\varnothing D=198$



VME-Z $\varnothing D=248$



Damper position:

100 % = OPEN

0 % = CLOSED

Legend

V_{ZU} (m³/h) = Supply air volume

V_{ZU} [l/s] = Supply air volume

ρ (kg/m³) = Density

Δp_w (Pa) = Effective pressure




Volumetric Flow Meter VME

Effective pressure (supply air)

Volumetric flow meter VME integrated in the connection piece of the plenum box

VME-Z $\phi D=298$

VME-Z $\phi D=353$



Damper position:

- 100 % = OPEN
- 0 % = CLOSED

Legend

- V_{ZU} (m³/h) = Supply air volume
- V_{ZU} [l/s] = Supply air volume
- ρ (kg/m³) = Density
- Δp_w (Pa) = Effective pressure




Volumetric Flow Meter VME

Effective pressure (return air)

Volumetric flow meter VME integrated in the connection piece of the plenum box

VME-A $\varnothing D=98$

VME-A $\varnothing D=123$



Damper position:

100 % = OPEN

0 % = CLOSED

Legend

V_{AB} (m³/h) = Return air volume

V_{AB} [l/s] = Return air volume

ρ (kg/m³) = Density

Δp_w (Pa) = Effective pressure




Volumetric Flow Meter VME

Effective pressure (return air)

Volumetric flow meter VME integrated in the connection piece of the plenum box

VME-A $\varnothing D=138$

VME-A $\varnothing D=158$



Damper position:

100 % = OPEN

0 % = CLOSED

Legend

V_{AB} (m^3/h) = Return air volume

V_{AB} [l/s] = Return air volume

ρ (kg/m^3) = Density


Δp_w (Pa) = Effective pressure

Volumetric Flow Meter VME



Effective pressure (return air)

Volumetric flow meter VME integrated into the connection piece of the plenum box

VME-A $\varnothing D=198$



VME-A $\varnothing D=248$



Damper position:

- 100 % = OPEN
- 0 % = CLOSED

Legend


- V_{AB} (m³/h) = Return air volume
- V_{AB} [l/s] = Return air volume
- ρ (kg/m³) = Density
- Δp_w (Pa) = Effective pressure

Volumetric Flow Meter VME



Effective pressure (return air)

Volumetric flow meter VME integrated in the connection piece of the plenum box

VME-A $\varnothing D=298$



VME-A $\varnothing D=353$



Damper position:

- 100 % = OPEN
- 0 % = CLOSED

Legend

- V_{AB} (m³/h) = Return air volume
- V_{AB} [l/s] = Return air volume
- ρ (kg/m³) = Density
- Δp_w (Pa) = Effective pressure